

SPECIAL INSTRUCTIONS

*PM-1052 Erosion Mask for
TECOM
Antenna (Ref: Drawing # 826064-001)*

Two PM-1052 Erosion Masks are joined together and mounted on a common hard plastic support form. After separation, each piece will protect one antenna.

*Place trim template over the mask and cut the film with a sharp blade.
(See Figure 1.)*

SPECIAL INSTRUCTIONS

*PM-1052 Erosion Mask for
TECOM
Antenna (Ref: Drawing # 826064-001)*

Two PM-1052 Erosion Masks are joined together and mounted on a common hard plastic support form. After separation, each piece will protect one antenna.

*Place trim template over the mask and cut the film with a sharp blade.
(See Figure 1.)*

g:\air\specinst\PM1052si.ins

9-22-2005