

SPECIAL INSTRUCTIONS

PM-1053 Erosion Boot for Chelton Radome

Q UAV Pod (Ref: Drawing # 230321-001)

13.A. Place trim template over the mask.

14. Using the edge of the template as a guide, trim the boot with an industrial knife or razor blade.

NOTE: Use new blade only.

CAUTION: Do not cut too deep. You do not need to cut all the way through the boot. You can feel the blade drag if it makes contact with the pod.

Go to Step 17.

SPECIAL INSTRUCTIONS

PM-1053 Erosion Boot for Chelton Radome

Q UAV Pod (Ref: Drawing # 230321-001)

13.A. Place trim template over the mask.

14. Using the edge of the template as a guide, trim the boot with an industrial knife or razor blade.

NOTE: Use new blade only.

CAUTION: Do not cut too deep. You do not need to cut all the way through the boot. You can feel the blade drag if it makes contact with the pod.

Go to Step 17.