

PM-2005

CAUTION: Polyurethane must be firmly attached to a solid substrate. If it spans a crack where it is not glued down, the material will vibrate during flight, work harden and become brittle. This can cause some of the material to crack or peel away. To avoid this problem and also address the need for the lens to be removable, trim along the edges of the lens.

When applying the mask to the fuel tank, use the squeegee to smooth the mask down. Using a sharp blade, separate the portion of the mask that covers the lens. Trim the edges on both sides of the separation, as required, to remove any material that is not glued down.

PM-2005

CAUTION: Polyurethane must be firmly attached to a solid substrate. If it spans a crack where it is not glued down, the material will vibrate during flight, work harden and become brittle. This can cause some of the material to crack or peel away. To avoid this problem and also address the need for the lens to be removable, trim along the edges of the lens.

When applying the mask to the fuel tank, use the

squeegee to smooth the mask down. Using a sharp blade, separate the portion of the mask that covers the lens. Trim the edges on both sides of the separation, as required, to remove any material that is not glued down.

g:\air\specinst\pm2005si.doc 8/21/03