

PM-2006
Lockheed C-130
Spinner Erosion Mask

It is important that the mask material is glued down firmly to the spinner around the hole at the tip and that the hole is not covered.

Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.

Each mask comes with 4 pieces of pre-cut tape. Install these wet, the same way you install the mask, on the transition leading edges between the main body of the spinner and the props.

PM-2006
Lockheed C-130

Spinner Erosion Mask

It is important that the mask material is glued down firmly to the spinner around the hole at the tip and that the hole is not covered.

Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.

Each mask comes with 4 pieces of pre-cut tape. Install these wet, the same way you install the mask, on the transition leading edges between the main body of the spinner and the props.