

SPECIAL INSTRUCTIONS FOR INSTALLING

PM-233L & R TWIN COMANCHE LOPRESTI WOW COWL MASKS

1. Review the instructions for installing masks, in our Shop manual.
2. The cowl should be free of wax, grease or other contaminants. Hands must be very clean or covered with rubber gloves.
3. Remove each mask from its support by cutting with a sharp blade.
4. Place each mask on the cowl without removing the release liner that covers the adhesive.
5. Move each mask about until you locate the position of best fit. Then place some small pieces of tape on the mask along the leading edge to help you locate this position again during installation.
6. CAUTION: In the wetting solution, use rubbing alcohol from the drugstore and distilled water. DO NOT USE AIRCRAFT DEICING ALCOHOL!
7. When removing the release liner, use the wetting solution liberally to prevent the mask from sticking to itself. Also wet the cowl so the mask will slide around to help you find the correct spot. Press the mask down along the leading edge first and then squeegee the moisture in small steps to the rear. If the rear is pressed in place first it will trap moisture under the mask.
8. Divide the overlap by cutting into both layers and leaving a strip that can be peeled off.
9. Pick up the upper edge and remove the strip of scrap underneath.
10. Inspecting the condition of the mask should be part of the pre-flight inspection. A damaged mask should be removed before flight.