

## *Special Instructions*

*PM-41*

*Canadair Challenger 600 Series*

*Ram Air Intake Erosion Mask*

*It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.*

*Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.*

# *Special Instructions*

*PM-41*

*Canadair Challenger 600 Series*

*Ram Air Intake Erosion Mask*

*It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.*

*Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.*

*g:\air\specinst\pm41si.ins*