

*PM-43  
Bombardier Global Express  
Ram Air Intake Erosion Mask*

*It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.*

*Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.*

*PM-43  
Bombardier Global Express  
Ram Air Intake Erosion Mask*

*It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.*

*Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.*