

Procedure for installing PM Research PM-560 protective mask on Comant CI-5000 Antenna

1. Review the PM Research shop manual addendum for procedures and materials required for working with PM Research polyurethane masks.
2. Place 4 small strips of tape on the center of the leading edge mask for positioning reference marks. One is placed at each end of the vertical edge and one is placed at the left and right limits of the top hat leading edge.