

*PM-84
Hawker 800 XP
Ram Air Intake Erosion Mask*

It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.

Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.

*PM-84
Hawker 800 XP
Ram Air Intake Erosion Mask*

It is important that the mask material is glued down firmly to the intake around the hole and that the hole is not covered.

Soon after installing the mask use a sharp blade to trim around the hole. Then use the squeegee to smooth the edge down.