

SPECIAL INSTRUCTIONS

PM-K2005

L-3 WESCAM M-15 Turret Kit

PM-2011 FLIR Ball Mask

2.A To make orienting the mask to the FLIR Ball easier, trim mask where yokes would be (See Figure 1.)

PM-2012 FLIR Yoke Mask Pair is joined together and mounted on a common support form.

PM-T2013

Erosion Tape

wet, the

install

FLIR Trunnion

is installed

same way you

the masks.

g:\air\specinst\pmK2005si.wpd 1/11/06