

SPECIAL INSTRUCTIONS

PM-146 Erosion Mask for Diamond DA-20 Katana Prop Tips Mask Set

Two PM-146 Erosion Masks are joined together and mounted on a common hard plastic support form. (Refer to Fig 1) After separation, each piece will protect a prop tip.

The thin film can be cut with a sharp blade without removing the staples. If preferred, they can be divided by cutting with scissors after the staples are removed and the joined masks lifted from the hard plastic.

Lightly scuff the prop surface where mask and tape will be applied, using sandpaper (600 Grit), then clean using wetting solution and paper towels prior to install.

Erosion tape can be used for the straight run from each mask. Install the masks first, then install the tape, squaring the end, if necessary, to ensure a close fit to each mask.